

TRANSIT BUSES A.M. GENERAL

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
96, 102 COACH	50	08	18	18

AVS

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
AVS22	03	03	32	32
AVS30/35	03	03	32	32
AVS40	03	03	32	32

BLUE BIRD

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
COMMUTER COACH	03	03	24	24
Q-BUS	93	99	24	24
ULTRA LF	05	05	32	32
ULTRA LF	03	04	28	28
XCEL 102	03	03	26	26

CARPENTER

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
CROWN	96	99	24	24

CHAMPION BUS

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
CONTENDER	97	97	28	28
CTS	93	03	24	24
SOLO	97	97	28	28
TROLLEY	03	03	24	24

CHANCE COACH

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
AH-28	93	03	20	20
CHG-28	83	93	20	20
OPUS	03	03	32	32
VS-24	83	93	20	20

CHICAGO BUS

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
ALL	01	01	24	24

CROWN COACH

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
TRANSIT BUS	69	81	20	20

DAIMLER CHRYSLER COMMERCIAL BUSE:

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
SLF 200	01	04	28	28

DINA

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
VIAGGIO 1000	97	97	28	28

EL DORADO

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
AXESS	03	03	32	32
E-Z RIDER	97	03	24	24
MST, MST II	93	03	24	24
TRANSMARK RE	97	03	24	24

ELF

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
200 SERIES	93	94	22	22

FLXIBLE CORP

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
96, 102 COACH	78	99	26	26
96, 102 COACH	64	77	20	20

GILLIG BUS

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
GERMAN COACH 32	97	03	26	26
LOW FLOOR	03	03	32	32
LOW FLOOR	97	02	22	22
PHANTOM COACH	03	03	24	24
PHANTOM COACH	97	02	22	22

GMC

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
RTS COACH	ALL		26	26
96, 102 COACH	ALL		18	18
96 PARLOR COACH	ALL		20	20

GOSHEN COACH

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
SENTINAL	97	01	24	24

IKARUS

Model	Start Year	End Year	Blade Length	
			Driver	Passenger

406	93	99	26	26
-----	----	----	----	----

MCI

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
A3	94	01	26	26
AMERICAN CLASSIC	03	03	82	82
COMMUTER COACH	03	03	28	28
DL3	94	01	26	26
HYBRID	03	03	28	28
ISTV	03	03	28	28
MC5, MC5A, MC5B	ALL	ALL	18	18
MC5C	ALL	ALL	18	18
MC6	ALL	ALL	18	18
MC7	ALL	ALL	18	18
MC8	ALL	ALL	18	18
MC9	ALL	ALL	18	18
UNIVERSITY TRANSPORTATI COACH	03	03	18	18
	ALL	ALL	28	28

NABI

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
ALL	00	03	32	32

NEOPLAN USA CORP.

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
AN340	03	03	32	32
AN345	03	03	32	32
AN335, AN435LF	03	03	28	28
AN440, AN440LF,AN440TLF	03	03	28	28
AN445TLF	03	03	28	28
AN460	03	03	26	26
AN SERIES	88	02	26	26

NEW FLYER INDUSTRIES

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
C30LF	03	03	26	26
C35LF	03	03	26	26
C40LF	03	03	26	26
D30LF	03	03	26	26
D35LF	86	03	26	26
D40i INVERO	03	03	32	32
D40LF	86	03	26	26
D60LF	93	03	26	26
D900	ALL	ALL	26	26
D901	80	85	26	26
DE40LF	03	03	26	26
DE60LF	03	03	26	26

NEW GOSHEN COACH

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
SENTRY	93	94	26	26

NOVA BUS

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
NOVA LFS	03	03	32	32
RTS	97	97	26	26

ORION

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
MODEL 1-7	93	03	26	26
MODEL 1-5	86	92	20	20

PREVOST

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
H-SERIES	03	03	28	28
LeMIRAGE XLII	03	03	28	28

SETRA

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
S215 HDH	03	03	28	28
S217 HDH	03	03	28	28

TMC

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
RTS COACH	87	99	26	26