

WESTERN STAR

Model	Start Year	End Year	Blade Length	
			Driver	Passenger
ALL CONVENTIONAL	01	05	20	20
ALL CONVENTIONAL (EXCEPT 3700 SERIES)	00	00	20	20
3700	00	00	22	22
ALL CONVENTIONAL	96	99	20	20
ALL CONVENTIONAL	90	95	18	18
ALL CONVENTIONAL (AIR Vacuum)	79	89	18	18
ALL CONVENTIONAL (ELECTRIC)	85	89	18	18
ALL COE	79	87	20	20